

INSTRUCTIONS FOR USE

- Gain access to the injectors and remove them.
- Place assembled cutter into injector recess.
- Select required reamer, place onto pilot post and tighten hex screw.
- Using the T bar supplied apply only a small amount of pressure whilst turning the cutter in a clockwise direction only. Use a small amount of light lubricant whilst performing the cut to reduce chattering and help give a flat cut. Do not over cut the seat only remove enough metal to form a good seat.

