



INSTRUCTIONS FOR:

# WINDSCREEN STAND FOLDING

MODEL NO: **WK4.V4**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions and maintained properly, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to Instruction Manual

## 1. SAFETY

- ✓ Ensure that the stand is on a level floor before loading.
- ✓ Ensure that all fastenings are tight.
- ✗ **DO NOT** use the stand for any other purpose than that for which it was designed.

## 2. INTRODUCTION

Lightweight tubular steel design with variable height facility. Large rubber suckers prevent screen from moving during preparation. Folding frame makes this ideal for both workshop and mobile screen preparation.

## 3. SPECIFICATION

Model No: ..... **WK4**  
 Width: ..... 1000mm  
 Folded Height: ..... 1200mm

## 4. ASSEMBLY

- 4.1. Attach rubber end caps (fig.1.1) to lower legs (fig.1.2).
- 4.2. Insert lower legs (fig.2.2) into top frame (fig.2.1.) and secure with eye bolt (fig.2.3), placing an M8 washer either side of the tube and securing with an M8 nut, the nut being secured on the outside of the frame.
- 4.3. Insert the other leg tubes into the top frame and secure with the eye hooks (fig.2.4), using washers and bolts as in section 4.2. Ensure that the hooks face inwards.
- 4.4. Connect the two frame members as in fig.1, using bolts (fig.5), washers (fig.2.8), centre washer (fig.2.6) and lock nut (fig.2.7).
- 4.5. Attach rubber cups (fig.1.6) by means of bolts (fig.1.5) washers (fig.1.6), tubes (fig.1.7) and nuts (fig.1.8)




fig.1




fig.2

### Environmental Protection



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal of it according to local regulations.

**NOTE:** It is our policy to improve products continually and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group,  
 Kempson Way, Suffolk Business Park,  
 Bury St. Edmunds, Suffolk,  
 IP32 7AR



01284 757500

01284 703534



www.sealey.co.uk

sales@sealey.co.uk