



VSE127H01



ITEM	PART NO	DESCRIPTION
A	VSE127H01-A	ADAPTOR (A)
B	VSE127H01-B	ADAPTOR (B)
C	VSE127H01-C	ADAPTOR (C)
D	VSE127H01-D	ADAPTOR (D)
E	VSE127H01-E	PIN


VSE127H02



ITEM	PART NO	DESCRIPTION
A	VSE127H02-A	ADAPTOR (A)
B	VSE127H02-B	ADAPTOR (B)
C	VSE127H02-C	ADAPTOR (C)
D	VSE127H02-D	ADAPTOR (D)


Issue: 1
 Issue Date: 140808

VSE127H03



ITEM	PART NO	DESCRIPTION
A	VSE127H03-A	ADAPTOR (A)
B	VSE127H03-B	ADAPTOR (B)
C	VSE127H03-C	ADAPTOR (C)
D	VSE127H03-D	ADAPTOR (D)
E	VSE127H03-E	ADAPTOR (E)
F	VSE127H03-F	ADAPTOR (F)
G	VSE127H03-G	SCREW (c/w NUT)

VSE127H04



ITEM	PART NO	DESCRIPTION
A	VSE127H04-A	ADAPTOR (A)
B	VSE127H04-B	ADAPTOR (B)
C	VSE127H04-C	ADAPTOR (C)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.