



Issue: 2
 Issue Date: 251108

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS107K.01	ROTARY BUTTON	13	HS107K.13	HEATING ELEMENT
2	HS107K.02	HOUSING (LEFT)	14	HS107K.14	SCREW
3	HS107K.03	PCB	15	HS107K.15	CABLE GRIP
4	HS107K.04	SCREW	16	HS107K.16	SWITCH
5	HS107K.05	MOTOR	18	HS107K.18	CAPACITOR
6	HS107K.06	MOTOR SUPPORT	19	HS107K.19	SWITCH COVER
7	HS107K.07	FAN	20	HS107K.20	TERMINAL BLOCK
8	HS107K.08	SCREW	21	HS107K.21	HOUSING (RIGHT)
9	HS107K.09	FAN COVER	22	HS107K.22	SCREW
10	HS107K.10	SCREW	23	HS107K.23	GASKET
11	HS107K.11	TUBE	24	HS107K.24	FRONT COVER
12	HS107K.12	MICA SHEET	25	HS107K.25	CORD SLEEVE

ACCESSORIES

ITEM	PART NO	DESCRIPTION
ACC1	HS107K.26	FISH TAIL NOZZLE (FLAT NOZZLE)
ACC2	HS107K.27	WIDE SCRAPER (SHOVEL)
ACC3	HS107K.28	DEFLECTOR (SPOON)
ACC4	HS107K.29	CONE NOZZLE
ACC5	HS107K.30	SCRAPER



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.