


Parts Information:
**Space Warmer® Paraffin/Kerosene/Diesel
 Heater 205,000Btu/hr with Wheels**
Model No: AB2050



Item	Part No.	Description
1	AB2050-01	Oil Drain Seal Ring
2	AB2050-02	Oil Drain Screw
3	AB2050-03	Fuel Tank
4	AB2050-04	Support Pin
6	AB2050-06	Cable Grip
7	AB2050-07	Ignition Transformer
8	AB2050-08	Support Plate for Ignition Transformer
9	AB2050-09	Fuel Filter
10	AB2050-10	Fuel Filter Seal Ring

Item	Part No.	Description
11	AB2050-11	Breather Cover
12	AB2050-12	Fuel Tank Cap
13	AB2050-13	Fuel Tank Cap Seal
14	AB2050-14	Fuel Tank Cap Shaft
15	AB2050-15	Oil Inlet Filter
16	AB2050-16	Oil Inlet Filter Holder
17	AB2050-17	Oil Filter Gauge
18	AB2050-18	Thermostat
19	AB2050-19	Thermostat Control Knob

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:
**Space Warmer® Paraffin/Kerosene/Diesel
Heater 205,000Btu/hr with Wheels
Model No: AB2050**

Item	Part No.	Description
20	AB2050-20	Light Cover
21	AB2050-21	On/Off Switch
22	AB2050-22	Control Panel
23	AB2050-23	Power PCB Support
24	AB2050-24	Power PCB
25	AB2050-25	Lower Cover
26	AB2050-26	Air Outlet Cover
27	AB2050-27	Support Ring
28	AB2050-28	Chamber Shield Hook
29	AB2050-29	Combustion Chamber Shield
30	AB2050-30	Chamber Shield Bracket
31	AB2050-31	Combustion Chamber
32	AB2050-32	Burner Support Plate
33	AB2050-33	Photocell Bracket
34	AB2050-34	Photocell Ass'y
35	AB2050-35	Re-Set Thermostat Bracket
36	AB2050-36	Re-Set Thermostat
37	AB2050-37	Flame Control Plate
38	AB2050-38	Nozzle Assembly
39	AB2050-39	Nozzle Adaptor

Item	Part No.	Description
40	AB2050-40	Air Hose
41	AB2050-41	Fuel Hose
42	AB2050-42	Ignition Electrode
44	AB2050-44	Solenoid Valve
45	AB2050-45	Solenoid Valve Bracket
46	AB2050-46	Fan Guard
47	AB2050-47	Motor Support
48	AB2050-48	Motor Assembly
49	AB2050-49	Fan
50	AB2050-50	Upper Cover
51	AB2050-51	Side Plate
52	AB2050-52	Wheel Axle
53	AB2050-53	Wheel Frame Support
54	AB2050-54	Split Pin
55	AB2050-55	Wheel
56	FWM12.S	Flat Washer M12 Zinc
57	SN12.SD	Steel Nut M12 Domed Zinc
58	AB2050-58	End Plug
59	AB2050-59	Handle

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk