



# JUNIOR TOY TOOL KIT 19PC

MODEL NO:JTK1

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Not suitable for children under 3

## 1. SAFETY

- WARNING! this product is unsuitable for children under the age of 3 years of age BSEN 71-1 Compliant.**
- WARNING! to be used under the supervision of an adult.**
- NOTE: Assembly should be completed by adults only.**
- ✓ Inspect tools regularly to ensure that they are in an adequate condition for safe use.
- ✓ Prevent unintentional starting. Ensure the drill drivers batteries are removed when not in use.
- ✗ **DO NOT** attempt to try and charge the battery pack on any of the range of Sealey main line chargers. It is not compatible.
- ✓ Only batteries of the same or equivalent type as recommended are to be used.
- ✗ **DO NOT** dispose of batteries in fire, as batteries may explode or leak.
- ✗ **DO NOT** mix old and new batteries or types of batteries (i.e. alkaline/standard/rechargeable).
- ✗ Using rechargeable batteries is not recommended due to possible reduced performance. Rechargeable batteries are only to be charged under adult supervision.
- ✗ **DO NOT** allow a child to put any of the toy tool set in their mouth small parts could be a choking hazard.
- ✗ **DO NOT** leave near an exposed heat source or naked flame.
- ✗ **DO NOT** get the drill or batteries wet or use in damp or wet locations.
- ✗ **DO NOT** submerge in water or liquids.
- ✗ **DO NOT** drop or throw the drill or components.
- ✗ **DO NOT** use tool set unless you have been instructed in its use by a parent or guardian.
- ✓ After use clean,inspect for damage and store in a safe,dry,location.
- ✓ Only for domestic use.

## 2. INSTRUCTIONS

All the basics for every budding builder to be able to help with DIY tasks around the home. Battery powered drill comes with three attachments. For added realism the drill is also fitted with a working light as well as forward and reverse motion for a range of purposes (requires 3 x AA batteries - not supplied). Suitable for children 3+ years old, BS EN 71-1 compliant. Contents: Tool case, spanner, adjustable wrench, pliers, hammer, saw, electric drill with assorted drill bits, screwdriver, 3x nuts, 3x bolts and 2x pre-drilled blocks.


## 3. SPECIFICATION

Model No:..... JTK1

Battery Size..... 3xAA (Not Supplied)

## 4. OPERATION

- 4.1. To fit Batteries see fig.1 and fig.2.and to remove the batteries in their pack from the equipment, depress the spring loaded button on the battery pack. Remove the battery pack by sliding out. **DO NOT TOUCH THE METAL BATTERY TERMINALS.**
- 4.2. **FITMENT OF BATTERIES**
- 4.3. Remove screw (Fig1.1) and then remove battery cover (Fig1.2)
- 4.4. Fit AA batteries x3 starting from spring end negative - (Fig.2.1) compressing spring and then slotting battery positive end + into the metal tipped end (Fig.2.2). 'Remove used batteries from the drill to prevent damage. Remove the batteries from the unit during extended periods of non-use'.



**4.5. USING THE DRILL**

- 4.6. Ensure that you have read, understood and comply with all the safety instructions in Section 1.
- 4.7. Refer to fig.3 and fig.4 for use.

**5. CONTENTS**

- 5.1. Tool case
- 5.2. Spanner
- 5.3. Adjustable wrench
- 5.4. Pliers, hammer, saw
- 5.5. Electric drill with assorted drill bits
- 5.6. Screwdriver
- 5.7. 3x nuts, 3x bolts and 2x pre-drilled blocks.



**ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE



**WEEE REGULATIONS**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

01284 757500

sales@sealey.co.uk

www.sealey.co.uk