



SPRING LOADED OIL REFILL SYRINGE 1.1L

MODEL NO: **VS406**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective clothing



Wear protective gloves

1. SAFETY

- WARNING!** Ensure health & safety, local authority, and general workshop practice regulations are strictly adhered to when using this equipment.
- ✓ Familiarise yourself with product application and limitations, as well as the specific potential hazards peculiar to this product.
- ✓ Maintain the product in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. *Use genuine parts only. Non authorised parts will invalidate the warranty.*
- ✓ Ensure safety eye protection and protective clothing are worn when using this product.
- ✓ Ensure that a vehicle which has been jacked up is adequately supported with axle stands.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ✓ Keep children and unauthorised persons away from the working area.
- ✓ Dispose of waste liquids in accordance with local authority regulations.
- ✗ **DO NOT** use to extract corrosive fluids.
- ✓ Keep the syringe clean and store in a safe, dry, childproof location.
- WARNING! DO NOT** allow uncontrolled discharge of fluids thus polluting the environment.

2. INTRODUCTION

The large internal spring allows one-person operation and refills automatically when the valve is opened. A multipurpose syringe with Viton® seal, ideal for transferring oils/fluids to vehicle components such as gearboxes and differentials. Translucent body allowing easy inspection of contents. Large 1.1L capacity, suitable for most gearboxes, differentials and transfer boxes. Storage hook.

3. SPECIFICATION

Model No:	VS406
Nett Weight:	1.3kg

4. INSTRUCTIONS

- 4.1. Pull handle until spring is fully loaded, then turn clockwise to secure the loading position.
- 4.2. Unscrew hose assembly, add lubricant directly into pump. Replace hose assembly.
- 4.3. Release handle counter-clockwise.
- 4.4. Open the red valve slowly and the spring will push out lubricant automatically.

5. MAINTENANCE

- 5.1. Wipe down after use. **DO NOT** use solvents.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk