


PARTS FOR: AIR ADHESIVE STRIPE REMOVING **TOOL PREMIER**

MODEL: SA95.V3



ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	SA95.V3-01	SPINDLE	18	SA95.V3-18	SPRING PIN (3x22)
2	SA95.V3-02	SPACER	19	SA95.V3-19	SAFETY LEVER ASS'Y
3	SA95.V3-03	BEARING HOUSING	20	SA95.V3-20	VALVE SHAFT
4	SA95.V3-04	BEARING (6201ZZ)	21	SA95.V3-21	O-RING (P4)
5	SA95.V3-05	CARRIER	22	SA95.V3-22	THROTTLE VALVE
6	SA95.V3-06	NEEDLE SPINDLE	23	SA95.V3-23	VALVE SPRING
7	SA95.V3-07	PLANET GEAR	24	SA95.V3-24	O-RING (P10A)
8	SA95.V3-08	INTERNAL GEAR	25	SA95.V3-25	AIR REGULATOR
9	SA95.V3-09	BEARING (626ZZ)	26	SA95.V3-26	SPRING PIN (2.5x20)
10	SA95.V3-10	FRONT PLATE	27	SA95.V3-27	O-RING (S22.4)
11	SA95.V3-11	SPRING PIN (2.5x5)	28	SA95.V3-28	EXHAUST SLEEVE
12	SA95.V3-12	CYLINDER	29	SA95.V3-29	INLET BUSHING
13	SA95.V3-13	ROTOR	30	SA95.V3-30	SEAL
14	SA95.V3-14	ROTOR BLADE	31	SA95.V3-31	HOUSING COVER
15	SA95.V3-15	REAR END PLATE	32	SA95.V3-32	PAD WHEEL
16	SA95.V3-16	BEARING (696ZZ)	33	SA95.V3-33	WRENCH (17mm)
17	SA95.V3-17	MOTOR HOUSING			

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.









