



Issue No: 2
 Date Issued: 130606

Item	Part No.	Description
1	SM1100.V2-01	Headstock (BLUE)
2	SM1100/02	Faceplate
3	SM1100/03	Driving Centre
4	SM1100/04	Spindle
5	SM1100/05	Key
6	SM1100/06	Bearing
7	SM1100/07	C-ring
8	SM1100/08	Spring
9	SM1100/09	Bracket, Shifting Lever
10	SM1100/10	C-ring
11	SM1100/11	C-ring
12	SM1100/12	C-ring
13	SM1100/13	Motor
14	SM1100/14	Key
15	SM1100/15	Screw
16	SM1100.V2-16	Cover, Motor (BLUE)
17	SM1100/17	Pulley, Motor, Left
18	SM1100/18	Pulley, Motor, Right
19	SM1100/19	Spring
20	SM1100/20	Sleeve
21	SM1100/21	C-ring
22	SM1100/22	Push-out Rod
23	SM1100/23	Handle
24	SM1100/24	C-ring
25	SM1100/25	Eccentric Rod
26	SM1100/26	Screw

Item	Part No.	Description
27	SM1100/27	C-ring
28	SM1100/28	Pulley, Spindle, Left
29	SM1100/29	V-belt
30	SM1100/30	Pulley, Spindle, Right
31	SM1100/31	Bearing
32	SM1100/32	Lock Nut
33	SM1100/33	Nut
34	SM1100/34	Clamp
35	SM1100/35	Nut, M4
36	SM1100/36	C-ring
37	SM1100/37	Turning Base
38	SM1100.V2-38	Bed (BLUE)
39	SM1100/39	Baffle
40	SM1100/40	Screw
41	SM1100/41	Hex Wrench
42	SM1100/42	Bolt A
43	SM1100/43	Clamp A
44	SM1100/44	Hex Nut
45	SM1100/45	Angular Setting Assembly
46	SM1100/46	Screw
47	SM1100/47	Spindle Wrench
48	SM1100/48	Gear Assembly
49	SM1100/49	Speed Label
51	SM1100/51	Hex Screw
52	SM1100/52	Rack
53	SM1100/53	Bolt B

Item	Part No.	Description
54	SM1100/54	Clamp B
55	SM1100/55	Eccentric Rod
56	SM1100/56	Tool Rest Body
57	SM1100/57	Handle Assembly
58	SM1100/58	Extension, Tool Rest
59	SM1100/59	Lock Handle, Tail Stock
60	SM1100/60	Tool Rest
61	SM1100/61	Tailstock Spur
62	SM1100/62	Tail Spindle
63	SM1100/63	Tailstock Screw
64	SM1100/64	Handle Assembly
65	SM1100.V2-65	Tail Stock (BLUE)
66	SM1100/66	Washer
67	SM1100/67	Hand Wheel
68	SM1100/68	Screw
69	SM1100/69	Screw
70	SM1100/70	Upper Cover, Stand
71	SM1100/71	Stand Leg I
72	SM1100/72	Stand Leg II
73	SM1100/73	Tool Table
74	SM1100/74	Switch
75	SM1100/75	Switch Box
77	SM1100/77	Carriage Bolt
78	SM1100/78	Washer
79	SM1100/79	Spring Washer