


AK293



AK293/01	Distributor Assy	AK293/16	Adjusting Ring
AK293/02	Flame Guard Assy	AK293/17	Adjusting Pin
AK293/03	Connector Tube	AK293/18	O-Ring
AK293/04	Air Sleeve	AK293/20	Piezo Assy
AK293/05	Nozzle Plate	AK293/21	Body Assy
AK293/06	Spacer	AK293/22	Filling Tube
AK293/07	Screen	AK293/23	Spring
AK293/08	Holder Bolt	AK293/24	Pin
AK293/09	Spring	AK293/25	O-Ring
AK293/10	Valve Gate Assy	AK293/26	O-Ring
AK293/11	Valve Body	AK293/27	Body
AK293/12	Connecting Tube	AK293/28	Plastic Cover
AK293/13	O-Ring	AK293/29	Screw
AK293/14	O-Ring		
AK293/15	Operating Pin		