



INSTRUCTIONS FOR: LADDER RACK CLAMPS

MODEL: **SLC2**

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS, AND CAUTIONS. USE THIS PRODUCT CORRECTLY, AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.


1. SAFETY INSTRUCTIONS

- X **DO NOT** use the ladder rack clamps if any parts are missing or damaged as this may cause failure and/or personal injury.
- **WARNING!** Due to the variety in design of vehicles and roof bars/racks, it is the user's full responsibility to ensure no damage occurs whilst using these ladder rack clamps. Correct attachment of clamps to a vehicle is therefore critical and is beyond control of the manufacturer, distributor, or supplier.
- **WARNING!** The user must secure the clamps and any ladders properly, checking the security frequently when in use.
- **WARNING!** Remove any loose objects from the ladders.
- **WARNING!** Avoid any protrusions beyond the side of the vehicle as these may present a risk of injury to passers-by.
- X **DO NOT** use the ladder rack clamps for any purpose other than that for which they are designed.
- X **DO NOT** secure any other items using the clamps. These are designed for ladders only.
- **WARNING!** Drive carefully - reduce speed accordingly when transporting ladders.
- ✓ Before every use check the clamps for security of fittings or any sign of wear and tear. Replace any worn or damaged parts.
- ✓ Check the ladders are stable before transit.
- **WARNING!** Be wary of the ladder protruding from the boundaries of the vehicle.
- **WARNING!** Remember the driver of the vehicle is responsible for the security and safety of the load carried.
- **WARNING!** The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.

2. INTRODUCTION & SPECIFICATION

Safe and easy way to secure ladders with a universal fitment for roof racks. Yellow phosphate finish for added corrosion resistance. Suitable for trades where ladders need to be transported safely for on-site applications. Supplied with two heavy-duty iron padlocks for security. Made in Britain and BS1706 approved.

Maximum ladder width: 365mm.



3. ASSEMBLY

- 3.1 **Assembly.**
- 3.1.1 Pre-assemble both of the ladder rack clamps as in fig.1 above.

4. SECURING LADDER TO RACK




4.1 SECURE LADDER TO RACK.

- 4.1.1 Inspect your roof bars/rack to ensure they are correctly fitted according to the vehicle manufacturer's guidelines and in a serviceable condition.
- 4.1.2 Place your ladder on the roof bars; depending on the weight and/or length of the ladder this may require two people.
- 4.1.3 Ensure that you do not have too much overhang at either end of your vehicle.
- 4.1.4 Pass the roof bar hook through the ladder and under one of the bars (fig.2).
- 4.1.5 Wind the lock bar down onto the clamp bar as in fig.3 until the ladder is firmly held **ensuring** that the ladder stops are on either side of the ladder (fig.3).

Caution! Do not use too much force or you may damage the ladder and/or roof bars.

- 4.1.6 When the ladder is secured pass the padlock through the lock down bar and the clamp bar (fig.3). This will ensure that the load remains secure.

⚠ WARNING! Remember the driver of the vehicle is responsible for the security and safety of the load carried. Check the security of the ladder frequently during your journey



Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or phone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this equipment. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor
Sealey Group,
Bury St. Edmunds, Suffolk.

☎ 01284 757500
☎ 01284 703534

🌐 www.sealey.co.uk
✉ sales@sealey.co.uk