

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using these lockers.
- ✓ Locate locker in a suitable work area.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- WARNING!** Use locker on level and solid ground, preferably concrete.
- ✓ Keep the locker clean and tidy in accordance with good workshop practice.
- ✓ Keep children and unauthorised persons away from the work area.
- ✗ **DO NOT** use the locker for any purpose other than that for which it is designed.
- ✗ **DO NOT** use the locker outdoors.
- ✗ **DO NOT** get the locker wet or use in damp or wet locations or areas where there is condensation.
- ✗ **DO NOT** clean the locker with any solvents which may damage the surfaces or the protective coating.

2. INTRODUCTION

2.1. Introduction:

A range of lockers suitable for a variety of commercial applications. Single and two door models fitted with a hanging bar, single door model also has single shelf. Doors on all models are ventilated and fitted with cylinder locks, 2 sets of keys supplied per lock. Supplied flat packed.



2.2. Dimensions:

Width: 380mm, Depth: 450mm, Height: 1850mm.





3. ASSEMBLY

- 3.1. Lay out the back panel and the two side panels. The side panels have a cut-out at the front and a lip at the bottom. Slide the back panel into one of the side panels from the top (fig.1) and slide it all the way down (fig.2) - note that the shelf brackets line up.



- 3.2. Fit the other side panel to the back panel following the same procedure. Ensure that the side panels are supported in an upright position so that the panels are not twisted.
- 3.3. Carefully stand the unit up, again ensuring that the panels are not twisted, two people may be required for this.

- 3.4. Fit the door frame panel into the unit from the inside, locating the frame with the side panels at the top (fig.3) and bottom. Once located push fit them together until they lock into place.
 - 3.5. Fit the locker top from the top, ensuring that the three lips locate within the brackets at the back and sides, when they are lined up, apply pressure and lock the top into place (fig.4).
- NOTE:** the shelves and top are identical.



- 3.6. Fit the shelves into the locker following the same procedure as for the locker top.
- 3.7. Place hanging bar in position (SL1D and SL2D only) by pushing it into position (fig.4) and fit the mirror in its position inside the door.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.
IMPORTANT: No liability is accepted for incorrect use of this product.
WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.
INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.